

Project:

## Indiana City - Bottling House

View:

Top View - walls  
"folded out"

Scale:

 $3/32" = 1'$ 

Suggested Auralex Products:

- (33) 2"x2'x4' ProPanel Panels Mounted on Walls
- Mounting Hardware
- (14) 2"x2'x4' SonoFiber Panels Mounted on Ceiling Above Stage

*ISO Series*

SubDude-HT Monitor Isolators

ProMAX V2 Portable Absorption Panels

Notes:

1. Space **ProPanel Panels** evenly over the walls as shown, and they should help control overall reverberation and Axial Modes. Use Standard Mounting Clips in high traffic areas, And Offset Impaling Clips where possible.

2. Adhere or affix **SonoFiber Panels** to the ceiling above stage as indicated.

3. In the event of HVAC, Lighting Fixtures, etc. that will hinder product placement, adjust panel orientation to fit.

4. Note that I have listed some of our *ISO (Instant Sound Optimizer) Products* that you might find useful. These products are effective as a supplement to room treatment or in stand alone applications. They are designed to enhance the tonal clarity of your sound sources and refine the accuracy of your microphones.

The treatment shown to the right can help to improve the sound quality inside the room.  
For additional tips on sound isolation, visit [www.acoustics101.com](http://www.acoustics101.com).



9955 Westpoint Drive, Suite 101  
Indianapolis, IN 46256  
(800) 959-3343  
(317) 842-2600  
[www.auralex.com](http://www.auralex.com)

Layout by: Joe Milton

